



AKD4220-A

AK4220 Evaluation Board Rev.0

GENERAL DESCRIPTION

AKD4220-A is an evaluation board for AK4220 that has various 7:3 audio and 6:3 video switches. This board can achieve the interface with AV systems via RCA connectors.

■ **Ordering guide**

- AKD4220-A --- AK4220 Evaluation Board
- 10-wire flat cable for connection with printer port of PC (IBM-AT compatible machine), control software for AK4220, driver for control software on Windows 2000/XP are packed with this.
- Control software does not work on Windows NT
- Windows 2000/XP needs an installation of driver.
- Windows 95/98/ME does not need an installation of driver.

FUNCTION

- **RCA connectors for analog audio: 7 inputs 3 outputs**
- **RCA connectors for video: 6 inputs, 3 outputs**
- **10-pin header for I²C/4-wire serial control**




Figure 1. AKD4220-A Block Diagram
 * Circuit diagram and PCB layout are attached at the end of this manual.

EVALUATION BOARD MANUAL

■ Operation sequence

1) Set up power supply lines.

Name of jack	Color of jack	Voltage	Used for	Open / connect	Default Setting
+12V	Green	+12V	Regulator (T1)	Should be always connected when power supply lines are supplied from regulator of T1. In this case "JP9 (REG)" is set to short.	+12V
AVDD	Red	+5V	AVDD of AK4220	Should be always connected when AVDD is not supplied from regulator of T1. In this case "JP9 (REG)" is set to open.	Open
VVDD1	Bule	+5V	VVDD1 of AK4220	Should be always connected when AVDD is not supplied from regulator of T1. In this case "JP10 (VVDD1)" is set to open.	Open
D5V	Red	+5V	Regulator (T2)	Should be always connected when JP2(DVDD_SEL) is set to DVDD side. Can be open when JP2(DVDD_SEL) is set to REG side.	Open
DVDD	Orange	+3.3V	DVDD of AK4220	Should be always connected when DVDD is not supplied from regulator of T1 and T2. In this case "JP15 (DVDD)" is set to open.	Open
D3.3V	Orange	+3.3V	Digital Logic	Should be always connected when D3.3V is not supplied from regulator of T1 and T2. In this case "JP13 (D3.3V)" is set to open.	Open
AGND	Black	0V	Analog Ground	Should be always connected.	0V
VVSS	Black	0V	Analog Ground	Should be always connected.	0V
DGND	Black	0V	Digital Ground	Should be always connected, when JP1 (GND) is set to open.	0V

Table 1. Set up the power supply lines

(Note) Each supply line should be distributed from the power supply unit.

2) Set-up jumper pins and DIP switches. (See the followings.)

3) Power on.

AK4220 should be reset once bringing SW2 (PDN) to "L" upon power-up.

■ Set up jumper pins

1. JP1 (GND) : Analog ground and Digital ground
 OPEN : Separated.
 SHORT : Common. (The connector “DGND” can be open.) <Default>
2. JP9 (REG) : AVDD, VVDD1 of the AK4220, and regulator of T2 (TA48M033F)
 OPEN : AVDD is supplied from “AVDD ” jack. (“+12V” jack should be open)
 SHORT : AVDD is supplied from regulator of T1 (NJM78M05FA). < Default >
3. JP16 (AVDD) : AVDD of the AK4220
 OPEN : AVDD is supplied from “AVDD ” jack.
 SHORT : AVDD is supplied from regulator of T1 (NJM78M05FA).
 (“AVDD” jack should be open) < Default >
4. JP10 (VVDD1) : VVDD1 of the AK4220
 OPEN : VVDD1 is supplied from “VVDD1 ” jack.
 SHORT : VVDD1 is supplied from regulator of T1 (NJM78M05FA).
 (“VVDD1” jack should be open) < Default >
5. JP11 (D-A) : Regulator of T2 (TA48M033F)
 OPEN : Regulator of T2 (TA48M033F) is supplied from “D5V ” jack.
 SHORT : Regulator of T2 (TA48M033F) is supplied from regulator of T1 (NJM78M05FA).
 (“D5V” jack should be open) < Default >
6. JP15 (DVDD) : DVDD of the AK4220
 OPEN : DVDD is supplied from “DVDD ” jack.
 SHORT : DVDD is supplied from regulator of Regulator of T2 (TA48M033F).
 (“DVDD” jack should be open) < Default >
7. JP13 (D3.3V) : Power of digital logic
 OPEN : D3.3V is supplied from “D3.3V ” jack.
 SHORT : D3.3V is supplied from regulator of Regulator of T2 (TA48M033F).
 (“D3.3V” jack should be open) < Default >
8. JP12 (VVDD2) : Should be open.

■ Set up DIP switches

SW1 Setting for I2C of AK4220

Pin No.	Pin Name	ON (“H”, “1”) / OFF (“L”, “0”)	Default
1	I2C	Control mode Select	ON (“H”, “1”)
2	CAD1	Chip Address Select (Note1)	OFF (“L”, “0”)
3	CAD0	Chip Address Select (Note1)	OFF (“L”, “0”)

Table 2. SW1 Setting for I2C of AK4220

(Note1) Chip Address is selected by CAD1, CAD0 pin (CAD10=“00”, “01”, “10”, “11”)

■ The function of the toggle SW

[SW2] (PDN): Resets the AK4220. Keep “H” during normal operation.

■ Indication for LED

[LE1] (INT): Monitor INT0 pin of the AK4220. LED turns on when channel dependent audio input detect circuit and video signal detect circuit of the AK4220.

[LE2 ~ 6] (Q0 ~ 4): Monitor Q0 ~ 4 pin of the AK4220.

■ **Serial Control**

The AK4220 can be controlled via the printer port (parallel port) of IBM-AT compatible PC. Connect printer port (parallel port) of PC and PORT2 (CTRL) of AKD4220-A by 10-wire flat cable (packed with AKD4220-A). Take care of the direction of 10-pin connector and 10-pin header.

The control software packed with this evaluation board supports 4-wire serial control only.





Figure 2. 10-wire flat cable, 10-pin connector, and 10-pin header


(1) 4-wire Serial Control Mode

The jumper pins should be set to the following.



(2) I²C-bus Control Mode

The jumper pins should be set to the following. <Default>



■ Input / Output circuit & Set-up jumper pin for Input / Output circuits

(1) Audio Input Circuit

GND1, LIN+1, RIN+1~ GND7, LIN+7, RIN+7 Input circuits




Figure 3. GND, LIN+, RIN+ Input circuit

(2) Audio Output Circuit

LOUT1/ROUT1 ~ LOUT3/ROUT3 Output circuits




Figure 4. LOUT/ROUT Output circuit

(3) Video Input Circuit

VIN1 ~ VIN6 Input circuits




Figure 5. VIN Input circuit

(4) Video Output Circuit

VOUT1 ~ VOUT3 Output circuits






Figure 6. VOUT Output circuit

(4-1) "DC Output" is output from J34, J35 and J36 connector. (SAGN bit = 1) <Default>

JP2/JP4/JP6
SAG1-1/SAG2-1/SAG3-1




JP3/JP5/JP7
SAG1-2/SAG2-2/SAG3-2




(4-2) "SAG Trimming Circuit" is output from J34, J35 and J36 connector. (SAGN bit = 0)

JP2/JP4/JP6
SAG1-1/SAG2-1/SAG3-1



JP3/JP5/JP7
SAG1-2/SAG2-2/SAG3-2



Control Software Manual

■ Set-up of evaluation board and control software

1. Set up the AKD4220-A evaluation board according to the above instructions.
2. Connect PC with AKD4220-A by 10-line type flat cable (packed with AKD4220-A). Please note the direction of the 10pin header.
3. Insert the CD-ROM labeled “AKD4220-A Evaluation Kit” into the CD-ROM drive.
4. Access the CD-ROM drive and double-click “akd4220-a.exe.” Set up the control program as needed.
5. Evaluate according to the following.

■ Operation flow

1. Set up and open the control program as above.
The following operation screen will be shown. (Default setting)




Figure 1. Control software window

2. Click “Port Reset” button.
Enter desired register setting and begin evaluation.

■ Button Functions

1. [Port Reset] : Set up USB interface board (AKDUSBIF-B).
2. [Write default] : Initialize all register settings.
3. [All Write] : Write all registers currently displayed.
4. [All Read] : Read all current register settings.
5. [Save] : Save the current register setting to .akr file.
6. [Load] : Load register setting from saved .akr file.
7. [All Reg Write] : Write to all registers by keyboard operation
8. [Data R/W] : Read/write register data by keyboard operation.
9. [Sequence] : The sequence of register setting can be set and executed.
10. [Sequence (File)] : The sequence created by [Sequence] can be assigned and executed.
11. [Write] : Write data by mouse operation.
12. [Read] : Read data by mouse operation.
13. [Read] : Read and display all current register setting in register window (on right side of main window).
Different from [All Read] as it does not reflect to the register map.

■ Data Indication

Input data is indicated on the register map. Button DOWN with red label indicates “H” or “1” and button UP with blue label indicates “L” or “0”. Blank buttons are not defined in the datasheet.

■ Explanation of each dialog

1. [Write Dialog]: Dialog to write data by mouse operation

There are dialogs corresponding to each register address.

Click the [Write] button corresponding to each register address to open the dialog. If the checkbox next to the register is checked, “H” or “1” will be written to the register. If it is unchecked, “L” or “0” will be written to the register.

Click [OK] button to execute the write to the registers. To cancel, click [Cancel] button.

2. [Save] and [Load]

2-1. [Save]

Save the current register setting data. The extension of file name is “.akr”.

(Operation flow)

- (1) Click [Save] Button.
- (2) Enter a file name and push [Save] Button to save settings to .akr file.

2-2. [Load]

Write the register setting saved using [Save].

(Operation flow)

- (1) Click [Load] Button.
- (2) Select file (*.akr) and Click [Open] Button.

3. [All Register Write Dialog]

Write and execute the register settings created by [SAVE] function. Click [All Reg Write] button to open the dialog shown in **Figure 2**.




Figure 2. [All Reg Write] window

3-1. [Open] and [Write] button

- (1) Click [Open] button and select register setting file (*.akr).
- (2) Click [Write] button to execute register setting.

3-2. [Save] and [Open] buttons on right side

[Save]: Save register setting file as *.ak5 file.

[Open]: Load register setting file (*.ak5).

3-3. Note

- (1) All files must be in same folder for [Save] and [Open] function on right side.
- (2) If register setting is changed by [Save] Button in main window, the file should be loaded again in order to reflect the change.

4. [Data Read/Write Dialog]: Dialog to write data by keyboard operation

Address Box: Input registers address in 2 hexadecimal figures.

Data Box: Input registers data in 2 hexadecimal figures.

Mask: Input mask data in 2 hexadecimal figures. This value is AND-ed with input data.

Click [Write] button to execute the write to the registers. To cancel, click [Close] button.

To read the current register value for the specified address, click [Read].

5. [Sequence Dialog]

Set and execute register setting sequence.

- (1) Click [Sequence] Button.
- (2) Set the control sequence.
Enter Address, Data and Interval time. Enter "-1" to Address to end sequence at that step.
- (3) Click [Start] button to execute sequence.

The sequence can be paused by entering Interval="-1". Click [START] button to restart the sequence from the paused step.

This sequence can be saved and opened by [Save] and [Open] button at the bottom right of the dialog. The extension of file name is "aks".




Figure 3. [Sequence] window

6. [Sequence(File) Dialog]

Write and execute sequence created in [Sequence]. Click [Sequence(File)] button to open the dialog shown in Figure 4.




Figure 4. [Sequence(File)] window

6-1. [Open] buttons on left side and [Start] buttons

- (1) Click [Open] button and select the sequence file (*.aks).
- (2) Click [Start] button to execute the sequence.

6-2. [Save] and [Open] buttons on right side

[Save]: Save sequence file. The file name is *.ak4.

[Open]: Load saved sequence file (*.ak4).

6-3. Note

- (1) [Sequence(File)] does not support the pause function of [Sequence] function.
- (2) All files must be in same folder for [Save] and [Open] function.
- (3) When the sequence is changed in [Sequence], the file should be loaded again in order to reflect the changes.

7. [Loop Dialog]: Dialog to evaluate ATT of VOL Control

Under the Tool tab in the main window, there is a button for [Loop Setting].

Address Box: Input registers address in 2 hexadecimal figures.

Start Data Box: Input start data in 2 hexadecimal figures.

End Data Box: Input end data in 2 hexadecimal figures.

Interval Box: Interval for data write..

Step Box: Data changes by this step.

Mode Select Box:

By checking this check box, the data will countdown to start data after reaching end data.

[Example] Start Data = 00, End Data = 09

Data flow: 00 01 02 03 04 05 06 07 08 09 09 08 07 06 05 04 03 02 01 00

If unchecked, the loop ends after data reaches end data.

[Example] Start Data = 00, End Data = 09

Data flow: 00 01 02 03 04 05 06 07 08 09

To write input data to AK4220, click [OK] button. To cancel, click [Cancel] button.

MEASUREMENT RESULTS

■ Audio

[Measurement condition]

- Measurement unit : Audio Precision System two Cascade
- BW : 10Hz~20kHz
- Power Supply : AVDD=5V, VVDD1=5V, VVDD2=5V, DVDD=3V
- Temperature : Room
- Measurement signal line path: LIN+1/RIN+1 → LOUT/ROUT

Parameter	Input signal	Measurement filter	Results [dB]
S/(N+D) at 1Vrms Output	1kHz, 0dBV	20kLPF	93.2 / 93.1
DR	1kHz, -60dBV	22kLPF, A-weighted	96.2 / 96.2
S/N	Off	22kLPF, A-weighted	96.2 / 96.1

Plots

Figure 1-1. FFT (1kHz, 0dBV input) at 1Vrms output

Figure 1-2. FFT (1kHz, -60dBV input)

Figure 1-3. FFT (Noise floor)

Figure 1-4. THD+N vs. Input Level (fin=1kHz)

Figure 1-5. THD+N vs. fin (Input Level=0dBFS)

Figure 1-6. Linearity (fin=1kHz)

Figure 1-7. Frequency Response (Input Level=0dBV)

Figure 1-8. Crosstalk (Input Level=0dBV)

■ Video

[Measurement condition]

- Signal Generator : Sony Tectonics TG2000
- Measurement unit : Sony Tectonics VM700T
- Power Supply : AVDD=5V, VVDD1=5V, VVDD2=5V, DVDD=3V
- Temperature : Room
- Measurement signal line path: VIN1 → VOUT1

Parameter	Measurement conditions	Results	Unit
S/N	Input = 0% flat field Filter = Uni-weighted, BW= 15kHz to 5MHz SAG = 1	72.4	dB
Crosstalk	Input = 100% red(ENCRC), Measured at VOUT	-74.0	dB
DG	Input = Modulated Lamp SAG = 1	0.22	%
DP	Input = Modulated Lamp SAG = 1	0.91	deg.

Plots

Figure 2-1. Noise spectrum (Input=0% flat field, BW=15kHz to 5MHz, uni weighted, SAG=1)

Figure 2-2. Frequency Response (Input= Multi Burst, SAG=1)

Figure 2-3 Crosstalk (Input= 100% red (VIN1), measured at VOUT1)

Figure 2-4 Crosstalk (Input= 100% red (VIN2), measured at VOUT1)

Figure 2-5 DG, DP (Input= Modulated Lamp, SAG=1)

Plots (Audio)

AKM

AK4220 FFT LIN1/RIN1-->LOUT1/ROUT1 input=0dBV

11/17/05 10:47:28




Figure 1-1. FFT (fin=1kHz Input Level=0dBV)

AKM

AK4220 FFT LIN1/RIN1-->LOUT1/ROUT1 input=-60dBV

11/17/05 10:55:52




Figure 1-2. FFT (fin=1kHz Input Level=-60dBV)




Figure1-3. FFT (Noise Floor)




Figure1-4. THD+N vs. Input level (fin=1kHz)

AKM

AK4220 LIN1/RIN1-->LOUT1/ROUT1 THD vs.Input Frequency
Input=0dB

11/17/05 11:13:51




Figure1-5. THD+N vs. Input Frequency (Input level=0dBV)

AKM

AK4220 LIN1/RIN1-->LOUT1/ROUT1 Linearity fin=1kHz

11/17/05 11:22:34




Figure1-6.Linearity (fin=1kHz)

AKM

AK4220 LIN+1/RIN+1-->LINEOUT Frequency Response Input=0dBV

05/18/06 13:15:12





Figure1-7. Frequency Response (Input level=0dBV)

AKM

AK4220 Crosstalk input=0dBV
Red:RIN1-->LIN1, Blue:LIN1-->RIN1



Sweep	Trace	Color	Line Style	Thick	Data	Axis	Comment
1	1	Red	Solid	1	Anl.r.Crosstalk	Left	
1	2	Blue	Solid	1	Anl.r.Crosstalk	Left	

ADDA.at2c

Figure1-8. Crosstalk (Input level=0dBV)

Plots(Video)




Figure 2-1. Noise spectrum (Input=0% flat field, BW=15kHz to 5MHz, uni weighted, SAG=1)




Figure 2-2. Frequency Response (Input= Multi Burst, SAG=1)




Figure 2-4 Crosstalk (Input= 100% red (VIN1), measured at VOUT1)




Figure 2-4 Crosstalk (Input= 100% red (VIN2), measured at VOUT1)




Figure 2-5 DG, DP (Input= Modulated Lamp, SAG=1)

Revision History

Date (YY/MM/DD)	Manual Revision	Board Revision	Reason	Contents
06/06/12	KM083400	0	First Edition	
12/04/12	KM083401	0	Ver.1.1	Control software updated.

IMPORTANT NOTICE

- These products and their specifications are subject to change without notice.
When you consider any use or application of these products, please make inquiries the sales office of Asahi Kasei Microdevices Corporation (AKM) or authorized distributors as to current status of the products.
- Descriptions of external circuits, application circuits, software and other related information contained in this document are provided only to illustrate the operation and application examples of the semiconductor products. You are fully responsible for the incorporation of these external circuits, application circuits, software and other related information in the design of your equipments. AKM assumes no responsibility for any losses incurred by you or third parties arising from the use of these information herein. AKM assumes no liability for infringement of any patent, intellectual property, or other rights in the application or use of such information contained herein.
- Any export of these products, or devices or systems containing them, may require an export license or other official approval under the law and regulations of the country of export pertaining to customs and tariffs, currency exchange, or strategic materials.
- AKM products are neither intended nor authorized for use as critical components_{Note1}) in any safety, life support, or other hazard related device or system_{Note2}), and AKM assumes no responsibility for such use, except for the use approved with the express written consent by Representative Director of AKM. As used here:
 - Note1) A critical component is one whose failure to function or perform may reasonably be expected to result, whether directly or indirectly, in the loss of the safety or effectiveness of the device or system containing it, and which must therefore meet very high standards of performance and reliability.
 - Note2) A hazard related device or system is one designed or intended for life support or maintenance of safety or for applications in medicine, aerospace, nuclear energy, or other fields, in which its failure to function or perform may reasonably be expected to result in loss of life or in significant injury or damage to person or property.
- It is the responsibility of the buyer or distributor of AKM products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the above content and conditions, and the buyer or distributor agrees to assume any and all responsibility and liability for and hold AKM harmless from any and all claims arising from the use of said product in the absence of such notification.